



Installation instruction





C i50



Contura







Alt. A







Alt. B


















9A → 10





9B.1




9B.2 → 10





12

T20



811257 MAV Luckram Ci50-2
2016-08-30

Contura

NIBE AB · Box 134 · SE-285 23 Markaryd · Sweden
www.contura.eu

Contura reserves the right to change dimensions and procedures described in these instructions at any time without special notice. The current edition can be downloaded from www.contura.eu