



Installation instruction





C i50



Contura





Alt. A




Alt. B






1


PH2




2





3




4






7


X2




8




9A → 10





9B.1





9B.2 → 10





12

T20



Contura

NIBE AB · Box 134 · SE-285 23 Markaryd · Sweden
www.contura.eu

Contura reserves the right to change dimensions and procedures described in these instructions at any time without special notice. The current edition can be downloaded from www.contura.eu

811257 MAV Luckram Ci50-2
2016-08-30